

ClearClick® AM/FM Retro Radio with Bluetooth

Quick Start Guide & User's Manual



Full 5-Year Warranty

& Free USA-Based Tech Support

This product comes with a full 5-year warranty & free USA tech support from ClearClick®. As a small business, we're here to serve you! If you have any issues with our product, please contact us at support@clearclick.tech.



www.ClearClick.tech

Register Your Product & Browse Our Products

Thank you for your purchase! Make sure you register your product & check out our other unique & easy-to-use technology at:

www.ClearClick.tech

Safety Precautions

1. Do not disassemble the unit.
2. Do not operate the unit around water or rain. Do not operate the unit around any kind of machines or appliances (other than computers).
3. Turn off and unplug the unit when not in use.
4. Do not allow young children to use this device.

Thank You!

Thank you for your purchase of the ClearClick® AM/FM Retro Radio! (Model VR43) We appreciate your business.

At ClearClick®, we try to make our technology as clear to understand and use as possible. But if you get stuck at any point, you qualify for FREE USA-based tech support as a ClearClick® customer. Just email us at: support@clearclick.tech

(Make sure you explain your issue in detail and tell us that you're using our ClearClick® AM/FM Retro Radio). Our USA-based tech support team members will normally reply to you within 24-48 business hours.)


QUICK START – Listening To AM/FM Radio

1. Plug the power cord into a power outlet. (*North American 110V voltage only*).
2. Switch the left knob to either “AM” or “FM.”
3. Turn on the radio by turning the VOLUME (ON/OFF) knob clockwise.
4. Use the tuning knob to select your desired radio station.
5. Use the volume control knob to adjust the volume.
NOTE: To improve the reception of your radio, adjust the pigtail antenna in the back of the radio.

QUICK START – Playing Music via Bluetooth

1. Plug the power cord into a power outlet. (*North American 110V voltage only*). Turn on the radio by turning the VOLUME (ON/OFF) knob clockwise.
2. Switch the left knob to “BT.” (Bluetooth mode) The Bluetooth indicator LED will light up blue.
3. On your phone, tablet, or other Bluetooth device, turn on Bluetooth and scan for devices. Connect to the “Vintage Radio” device.
4. Use the volume control knob to adjust the volume. (Note: You may also need to adjust the volume on your phone or tablet.)

Radio Diagram



1. Function switch knob
2. Bluetooth indicator LED
3. Tuning knob
4. Power ON/OFF and volume control knob
5. Speaker



Need Help With
Anything? We Are Here
To Help! Email Us At:

support@clearclick.tech



www.ClearClick.tech