

ClearClick® Retro Bluetooth Speaker

Quick Start Guide & User's Manual



Full 5-Year Warranty +

FREE USA-Based Tech Support

If you have any issue or question regarding this product, **contacting us directly** is the fastest way to resolve the issue. We are ClearClick®, a small USA-based business, and we stand behind our products with a full 5-year warranty & free USA tech support. If you have any issues with our product, **please contact us at support@clearclick.tech**.



www.ClearClick.tech

Register Your Product & Browse Our Products

Thank you for your purchase! Make sure you register your product & check out our other unique & easy-to-use technology at:

www.ClearClick.tech

Safety Precautions

- 1) Do not disassemble the unit.
- 2) Do not operate the unit around water or rain.
- 3) Do not operate the unit around any kind of machines or appliances (other than computers).
- 4) Turn off and unplug the unit when not in use.
- 5) Do not allow young children to use this device.

Thank You!

Thank you for your purchase of the ClearClick® Retro Bluetooth Speaker (Model Number VB19)! We appreciate your business.

This speaker features 2.1 channels (2 stereo speakers + 1 subwoofer speaker) and a total of 45W output power.

At ClearClick®, we try to make our technology as clear to understand and use as possible. But if you need help at any point, we offer FREE USA-based tech support. Just email us at: support@clearclick.tech.

(Make sure you explain your issue in detail and tell us that you're using our ClearClick® Retro Bluetooth Speaker (Model Number VB19). Our USA-based tech support team members will normally reply to you within 24-48 business hours -- usually less.)

To get started with your ClearClick® Retro Bluetooth Speaker, please see the quick start [guide](#) on the following pages.

What's In The Box

- ClearClick® Retro Bluetooth Speaker (VB19)
with Bass & Treble Control & 45W Output Power
- Power Cord
- User's Manual

NOTE: If you believe you are missing any parts, or if you received a part that is broken, please contact us directly at parts@clearclick.tech. For all other technical issues or support, please contact us at support@clearclick.tech.

MORE PRODUCTS YOU MIGHT LIKE FROM



**Cassette2USB Converter
(Convert Audio Tapes To Digital)**



**QuickConvert Photo, Slide, &
Negative Scanner**



**Video2Digital Converter (Convert
Video Tapes To Digital)**



**Film2USB Converter (Slide & Negative
Scanner)**



Retro Wooden Radio with Bluetooth

LEARN MORE & BUY NOW AT

WWW.CLEARCLICK.TECH

QUICK START – Playing Music via Bluetooth

1. Plug the power cable into a power outlet.
2. Flip the power switch to “ON.”
3. After 1-2 seconds, the speaker will start up and will be in “Bluetooth” mode by default.
4. On your phone, tablet, or other Bluetooth device, scan for Bluetooth devices and connect to the one named “ClearClick.”
5. The blue LED on the front will become solid blue once the speaker is connected to your Bluetooth device.
6. Start playing music on your Bluetooth device. Turn the volume control knob to adjust the volume. (NOTE: You may need to adjust the volume on your phone or Bluetooth device as well.)
7. Adjust the bass and treble levels as desired.

QUICK START – Playing Music via AUX IN

1. Plug the power cable into a power outlet.
2. Flip the power switch to “ON.”
3. After 1-2 seconds, the speaker will start up in “Bluetooth” mode by default.
4. Switch the speaker to “AUX” mode by pressing the “MODE” button.
5. Use a 3.5mm aux cable to connect your speaker to a phone, tablet, or MP3 player.
6. Start playing music on your phone, tablet, or MP3 player, adjusting the volume both on the device and on the speaker.
7. Adjust the bass and treble levels as desired.

Frequently Asked Questions (FAQ)

1. I can't connect the speaker to Bluetooth on my phone or tablet.

A. Make sure the speaker is turned on and in "Bluetooth" mode. The LED on the speaker should be blue.

B. If you have previously connected the speaker to any other Bluetooth devices, disconnect those from the speaker, or turn off Bluetooth on those devices.

C. Test the speaker with another phone or Bluetooth device.

2. There's another problem or issue with my speaker.

If you have any issue or question regarding this product, please contact us directly to resolve the issue. We are ClearClick®, a small USA-based business, and we stand behind our products with a full 5-year warranty & free USA tech support. If you have any issues with our product, please contact us at support@clearclick.tech.



www.ClearClick.tech