

ClearClick® Suitcase-Style Turntable with USB-Out Recording

Quick Start Guide & User's Manual



Full 1-Year Warranty & Free USA Tech Support

This product comes with ClearClick®'s **full 1-year warranty & free USA tech support**. As a small business, we're here to serve you! If you have any issues with our product, please contact us at support@clearclick.tech.



www.ClearClick.tech

This document © 2016 ClearClick Software LLC.
All rights reserved. Do not reproduce in any form without permission.

Table of Contents

Registration Information & Safety Instructions.....	2
Thank You & What's In The Box.....	3
Quick Start Guide #1: Playing Records.....	4
Quick Start Guide #2: Transferring Records.....	5
Turntable Diagram.....	7
Warranty Conditions.....	8
Tech Support Information.....	8

Register Your Product & Browse Our Products

Thank you for your purchase! Make sure you register your product & check out our other unique & easy-to-use technology at:

www.ClearClick.tech

Safety Precautions

1. Do not disassemble the unit.
2. Do not operate the unit around water or rain. Do not operate the unit around any kind of machines or appliances (other than computers).
3. Turn off and unplug the unit when not in use.
4. Do not allow young children to use this device.

Thank You!

Thank you for your purchase of the ClearClick® Suitcase-Style Turntable (with USB-Out Recording)! We appreciate your business.

At ClearClick®, we try to make our technology as clear to understand and use as possible. But if you get stuck at any point, you qualify for FREE USA-based tech support as a ClearClick® customer. Just email us at:

support@clearclick.tech

(Make sure you explain your issue in detail and tell us that you're using our ClearClick® Suitcase-Style Turntable (with USB Recording). Our USA-based tech support team members will normally reply to you within 24-48 business hours.)

To get started with your ClearClick® Suitcase-Style Turntable, please see the two quick start guides on the following pages.

What's In The Box

- ClearClick® Suitcase-Style Turntable
- Power Adapter
- USB Cable
- Software CD
- User's Manual

NOTE: If you believe you are missing any parts, or if you received a part that is broken, please contact us directly at parts@clearclick.tech. For all other technical issues or support, please contact us at support@clearclick.tech.

Quick Start Guide #1: How To Play A Record

1. Open the ClearClick® Suitcase-Style Turntable.
2. Power your turntable by using the included power adapter (plugging it into an outlet) or the included USB cable (plugging it into your computer).
3. Turn on the turntable by turning the volume knob clockwise.
4. Load a record onto the turntable.
5. Remove the protective twist ties on the turntable arm and the protective plastic cap on the cartridge/stylus.
6. Carefully lift the turntable arm and place it on your record. The turntable will begin to spin and your record will begin to play.
7. Adjust the volume knob if necessary.
8. To connect your turntable to speakers or headphones, use the “headphone” jack on the top of the turntable or the “RCA” line-out ports at the back of the turntable.
9. To play music from your MP3 player, smartphone, or tablet through the turntable’s built-in speakers, connect your device to the “AUX-IN” port in the back of the turntable. (1/8” aux cable not included.)
10. To transfer your record to your PC or Mac, follow the instructions in quick start guide #2.

Quick Start Guide #2: How To Transfer A Record To Digital MP3

1. Insert the included software CD into your PC or Mac.

(If your computer does not have a CD drive, you may also download the software from the “Downloads” page on our website: www.ClearClick.tech)

2. Browse the CD contents and double-click the correct “SETUP” file.

Windows Users: Run the file marked “SETUP-PC”


Macintosh Users: Run the file marked “SETUP-Mac”

3. If you are using a PC, the setup wizard will appear. Click “Next” in the prompts until the software is fully installed.

If you are using a Mac, drag the “Audacity” software icon into your Applications folder to install the software.


4. After the software is installed, plug the turntable into your PC or Mac using the included USB cable.
5. Open the “Audacity” software that you just installed on your PC or Mac. **NOTE:** the turntable must already be plugged in BEFORE opening the software.
6. In the software, click “Edit -> Preferences” (or Audacity -> Preferences on Mac).

7. In the dialog, set the “Recording Device” to the correct settings, as shown below. It should read something like: “USB Microphone.” Also, set Channels to “2 (Stereo).”



8. Load a record onto the turntable and start playing it (as described in Quick Start Guide #1).
9. Click the “Record” icon in the software, and your record will start transferring to your computer!
10. When the record has finished playing, click the “Stop” icon in the software.
11. To save your recorded audio, click File -> Export Audio (Audacity -> Export Audio on Mac).
12. Choose the name, location, and file type that you’d like to save your audio file as, and click “Save.” We recommend saving in “MP3” format.
13. The first time that you save an MP3 recording, the software may prompt you for a file called “lame_enc.dll.” This file is located on the installation CD. Browse the CD and select this file to allow the software to install this file.
14. Your audio will be saved as a digital MP3 file!

Turntable Diagram



14 15 16 17 18

- | | | |
|------------------------------|----------------------------------|-------------------------|
| 1. 45-RPM Single Adapter | 2. Turntable Arm | 3. Turntable Arm Lifter |
| 4. "Auto Stop" On/Off Switch | 5. Power Indicator | 6. Speed Selector |
| 7. Turntable Arm Holder | 8. Power Switch & Volume Control | |
| 9. Cartridge/Stylus | 10. Headphone Jack | 11. Turntable |
| 12/13. Front Speakers | 14. USB-Out Port | 15. AUX-In Port |
| 16. Right RCA-Out | 17. Left RCA-Out | 18. Power Jack |

Turntable Warranty Conditions

This product is fully warranted against defective materials and manufacturing faults for a period of twelve months from the date of registered purchase under the following provisions. This warranty does not cover damage from accidents or abuse.

If you believe you have a defective product, please contact us at support@clearclick.tech. We will diagnose the issue, and if your product is indeed defective, we will replace it entirely at our cost.

Need Help? Free USA-Based Tech Support

Open a support ticket and we'll get back to you within 24-48 business hours! (If you have not received a response within that time frame, check your SPAM folder.)

Just visit: <http://Support.ClearClickSoftware.com/>

Or email us at: support@clearclick.tech

